



- ① TREE PER PLANTING PLAN.
- ② SPLICE BOX
- ③ ROOTBALL OF TREE.
- ④ BACKFILL MIX PER PLAN.
- ⑤ EARTH WATERING BASIN.
- ⑥ NATIVE SOIL.
- ⑦ WATERMARK MODEL 200SS SOIL MOISTURE SENSOR. INSTALL SENSOR ADJACENT TO ROOTS AT A DEPTH NEAR THE MIDDLE OF THE ROOTBALL. WIRES SHALL RUN TO GRADE AND BE PLACED IN A 6" ROUND VALVE BOX AND SPliced TO CONNECTED EQUIPMENT. INSTALL PER MANUFACTURER SPECIFICATIONS.
- ⑧ FINISH GRADE

#### NOTES:

- LOCATE SENSORS AT APPROPRIATE DEPTH FOR PLANT MATERIAL.

NO SCALE

## WATERMARK TREE/SHRUB INSTALLATION