


IRROMETER®

1425 PALMYRITA AVE

RIVERSIDE, CA 92507

P: 951.682.9505

E: TECHSUPPORT@IRROMETER.COM



① EXISTING TREE

③ SUBGRADE

② IRROMETER TENSIO METER

④ ROOTZONE

NOTES:

- SET TIPS IN ACTIVE ROOT SYSTEM AREA IN TREE ROW.
- SENSOR LOCATION SHOULD BE NEAR DRIPLINE OF TREE AND ON THE SOUTH WEST SIDE IN NORTHERN HEMISPHERE.
- IF UTILIZING FURROW IRRIGATION, ANGLE TUBES SLIGHTLY TOWARDS FURROW.
- WITH SPRINKLER IRRIGATION, LOCATE IRROMETERS IN SPRINKLER WETTED PATTERN.
- WITH DRIP IRRIGATION, LOCATE IRROMETERS 12" - 18" FROM EMITTER, OR 24" - 36" FROM A MICRO SPRINKLER.
- IRROMETER PLACEMENT DEPTH IS A FUNCTION OF CROP ROOT DEPTH.

NO SCALE

IRROMETER INSTALLATION - ORCHARDS